


# kreon

## technics




Name	Reference	Voltage ⚡	Drive current
Module 120 QT12-ax	KR907813	12V	
Module 120 HIT-TC-CE	KR907803	230V/1,5kV	
Module 120 LED	KR907833		500mA or 700mA

The luminaire must not under any circumstances be covered with heat insulating covers or similar materials.  
Cables must not touch the luminaire housing.  
The connection cable must be routed so that it does not touch the lamp when the luminaire is tilted.

## 1 dimensions

## 2 installation

To install the plasterkit.  
See installation manual KR8170001755 or KR8070002005.



Bend the springs to remove the filterholder.

Insert the reflector in the movement mechanism.


## 3 installation

Insert the reflector in the socketholder.  
See installation manual KR8200001557.

Optional: add extra filters to the filterholder.

Maximum capacity= one filters.

In case of QT12 and HIT-TC-CE add lamp.




## 4 installation

Align A with B and add the filterholder.


Add filterholder.

Please make sure that main voltage is disconnected before proceeding! ⚡






Install the correct gear with strain relief on the hollow ceiling.

## technics



make sure the female connector is wired the same as the male connector, 1 is + and red, 2 is - and black:




## 5 installation

In case of LED important: always check the polarity!!  
+ = red wire - = black wire


In case of qt12 or HIT-TC-CE connect the supply cable to the connector and use the strain relief.

Put the assembly in the plasterkit.




## 6 installation



Push filterholder to rotate inner part manually.



Turn inner part manual.



To install the louvre see manual KR8170001761 or KR8170001762.